

Manual, Assembly instruction: Brodit 805910

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the mount is to be installed. Peel off the adhesive tape covers. Pull out the rubber sealant on the A-post slightly. Align the bottom edge of the mount with the top of the air vent by the left hand side.

2. Press the left part of the mount into the gap and hook it behind the A-post. Make sure the bottom edge of the mount with the top of the air vent by the left hand side.

3. Rotate the mount up into position. Press the mount upward/leftward and hook the right angled edge over the A-post. Press on the mount so the adhesive tapes attach properly.

4. The ProClip is in place.