

Manual, Assembly instruction: Brodit 806028

Left mount NOT for ID. Buzz Cargo.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder & equipment is to be attached after the mount is in place.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard overhang and the trim, to widen the gap. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover.

2. Press the lower part of the mount into the gap next to the gap opener. Press upward on the lower part so the angled edge goes all the way into the gap. Pull out the gap opener.

3. Pull the upper part of the mount upward and press it forward. Hook the upper edge over the trim. Press down on top of the mount so the angled edge hooks in place properly and the adhesive tape attaches.

4. The ProClip is in place.