

Manual, Assembly instruction: Brodit 806042

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the lower edge of the mount onto the frame surrounding the air vent.
2. Press the upper part downwards and forwards.
3. Press forwards on the upper part so the edge hooks under the frame surrounding the air vent.
4. The ProClip mount is in place.