

Manual, Assembly instruction: Brodit 806051

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Press the thin end of the included gap openers into the gap between the padded dashboard and the trim, to widen the gap.

2. Press the upper part of the mount into the gap between the gap openers. Pull out the gap openers.

3. Pull the lower edge downward. Keep the lower part on a distance from the padded dashboard so it does not touch it, and press it forward. Hook the lower edge of the mount under the padded dashboard. Press upward on the bottom of the mount so the angled edge hooks into place properly.

4. The ProClip mount is in place.