

Manual, Assembly instruction: Brodit 806060

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder & equipment is to be attached after the mount is in place.

1. Pull out the rubber sealant on the A-post slightly.
2. Press the angled edge on the lower part of the mount into the gap and hook it around the A-post.
3. Press the mount upward/forward and hook the angled upper edge around the A-post. Press down on top of the mount so the angled edge hooks all the way into place.
4. The ProClip mount is in place.