

## Manual, Assembly instruction: Brodit 806085

Left mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.**

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the lower lip of the mount on the air vent frame.
2. Press downward and forward on the top stem until the upper lip clips under the air vent frame. Press on the insides of the mount stems to ensure the lips are fully seated and the tape makes full contact with the frame.
3. The mount may be attached to the air vent on the passengers side.
4. The ProClip mount is in place.