

Manual, Assembly instruction: Brodit 806096

Left mount

1.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Press the upper edge of the mount into the gap between the frame surrounding the air vent and the dashboard.
2. Press forward on the bottom of the mount until the lower lip clips into the air vent housing.
3. The ProClip mount is in place.
4. The ProClip mount is in place.