

Manual, Assembly instruction: Brodit 806133

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Pull out the rubber sealant on the A-post slightly.

2. Press the angled edge on the lower part of the mount into the gap and hook it around the A-post.

2. Press the mount upward + forward and hook the angled upper edge around the A-post. Press down on top of the mount so the angled edge hooks all the way into place and the adhesive tape attaches properly.

4. The ProClip mount is in place.