

Manual, Assembly instruction: Brodit 806158

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Press the included Gap Opener (Spaltöffner) into the gap between the air vent frame and accent trim, to widen the gap. Center the mount over the air vent. Press the upper edge of the mount, with a cutout, into the gap next to the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner)s.

2. Press upward and forward on the bottom of the mount, until the lower edge hooks + clips onto the frame surrounding the air vent.

3. The ProClip mount is in place.

4. The ProClip mount is in place.