

Manual, Assembly instruction: Brodit 806180

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the grooved edge on the lower part of the mount over the frame surrounding the air vent.
2. Press downward on top of the mount and press the upper part forward. Hook the upper edge of the mount under the frame surrounding the air vent.
3. Press downward on the lower part of the mount and upward on the upper part so the adhesive tapes attach properly.
4. The ProClip mount is in place.