


Manual, Assembly instruction: Brodit 806222

Left mount


1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Pull out the rubber sealant on the A-post slightly.

2. Press the left edge of the mount into the gap and hook it behind the A-post.

3. Press the mount upward + forward and hook the right angled edge over the A-post. Press the right edge toward the A-post so the angled edge hooks into place properly. Press the rubber sealant back into place.

4. The ProClip is in place.