

Manual, Assembly instruction: Brodit 806251

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the frame surrounding the air vent and the dashboard. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover.

2. Press the upper part of the mount into the gap next to the Gap Opener (Spaltöffner). Pull out the Gap Opener (Spaltöffner).

3. Press the lower edge of the mount upward and forward. Keep the mount away from the padded dashboard so it will not touch the surface. Hook the lower edge of the mount into the gap between the panel surrounding the air vent and the dashboard. Press forward on the lower part of the mount so the edge hooks properly in the gap.

4. The ProClip mount is in place.