

Manual, Assembly instruction: Brodit 806269

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Hook the shorter, lower edge of the mount onto the edge under the trim between the air vents.
2. Rotate the mount up and hook the upper edge onto the top edge of the trim.
3. The ProClip mount is in place.
4. The ProClip mount is in place.