

Manual, Assembly instruction: Brodit 806281

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Press the thin end of the included Gap Opener (Spaltöffner) into the right side of the gap above the air vent, to widen the gap. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover.

2. Hook the lower edge of the mount under the dashboard edge above the vent.

3. Press forward on the faceplate to flex the mount. Hook the edge of the mount into the gap next to the Gap Opener (Spaltöffner). Press on the front and back edges of the mount to ensure each is fully and evenly seated. Pull out the Gap Opener (Spaltöffner).

4. The ProClip mount is in place.