

Manual, Assembly instruction: Brodit 806283

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Press the angled upper part of the mount into the gap between the frame surrounding the air vent and the panel.
2. Pull the lower part of the mount downward out from the panel and hook it under the panel.
3. Press forward on the lower part of the mount so the edge hooks properly in place.
4. The ProClip mount is in place.