


Manual, Assembly instruction: Brodit 806300

Left mount


1.)



2.)



3.)



4.)



Please read all instructions and review the pictures before installing the ProClip mount. Important: The mount must be installed before attaching any device holder, cradle, or other accessory.

1. Clean the installation area using the enclosed alcohol wipe. Remove the protective liner from the double-sided adhesive tape. Hook the grooved lower edge of the mount over the frame surrounding the air vent.
2. Press the upper part of the mount downward and forward so the grooved upper edge hooks under the frame surrounding the air vent.
3. The mount can also be placed onto the air vent on the passengers side.
4. The ProClip mount is in place.