

Manual, Assembly instruction: Brodit 810850

Headrest mount, NOT for models with built in monitor in headrest. For multimedia-monitors with a vertical slot in back. NOT for model with built-in monitor in headrest.

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the head rest mount. 1. Loosen the screws in the head rest mount so you get two parts. Press the flat part into the gap between the head rest and the front seats back support. 2. Press the flat part all the way in until it stops. 3. Place the front part of the mount on the back side of the head rest so the screws fit in the holes in the flat part. Tighten the screws on the frontside of the head rest mount, using the enclosed tool. Screw until the head rest mount is properly in place. 4. Adjust the face plate into desired position. Tighten the screw in the face plate. Note that the face plate will be harder + looser to tilt and swivel depending on how hard you tighten the screw. The head rest mount is in place.