

Manual, Assembly instruction: Brodit 830510

Console mount Adjustable console mount.



Attention! Read all instructions before attaching the ProClip.

1. Clean the surface at pos. 1 with the enclosed alcohol pad. Peel off the cover of the adhesive tape on the ProClip.

2. Hook the upper part of the ProClip, with adhesive tape, over the edge of the console into the gap at pos. 1. Hook the long angled lower part of the ProClip under the edge of the console at position 2.

3. Press the upper and lower part of the ProClip towards each other until the face of the ProClip has a flat/horizontal position. Tighten the nut with the enclosed tool. Place the enclosed cap over the nut.

4. Place the ProClip face plate over the ProClip so the holes match. Note that the position of the face plate changes depending on which way you hold the face plate. Screw the face plate onto the ProClip by using the enclosed screws. The ProClip is in place. In most vehicles the adjustable ProClip is placed on the right side of the console. However, in some vehicles it is placed on the left side of the console and in a few cases other placements i.e. mounting in the cup holder. When you choose the location for the ProClip it is important to make sure that the location spot will give the ProClip the necessary hold/grip onto the console and that it will not block the airbag.