

Manual, Assembly instruction: Brodit 832281

Console mount, Angled

1.)



Attention! Read all instructions before attaching the ProClip

1. Clean the surface at pos.
2. with the enclosed alcohol pad. Peel off the cover of the adhesive tape on the ProClip.
2. Hook the lower part of the ProClip. with angle, under the edge of the console frame at pos.
- 1.
3. Hooks the upper part of the ProClip, with adhesive tape, over the edge of the console frame at pos. 2.