

Manual, Assembly instruction: Brodit 832474

Console mount

1.)



Attention! Read all instructions before attaching the ProClip.

1. Clean the surface at pos. 1 with the enclosed alcohol pad. Peel off the adhesive tape cover on the ProClip.

2. Hook the left angled part of the ProClip, with adhesive tape, over the edge of the console frame at pos.

1.

3. Press on the right side of the ProClip so the angled edge hooks under the edge of the console frame at pos. 2.