

Manual, Assembly instruction: Brodit 832801

Console mount, Angled

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip Peel off the cover of the adhesive tape on the ProClip.

1. Press the upper part of the ProClip, with adhesive tape, into the gap between the console and the panel surrounding the gear shift.

2. Press downwards on the ProClip so the lower angled part hooks under the edge of the console.

3. The ProClip is in place

4. The ProClip is in place.