

Manual, Assembly instruction: Brodit 833297

Console mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin edge on the left side of the ProClip firmly into the gap between the center panel and the console edge.

2. Press down on the right side of the ProClip so the angled edge on the right side hooks under the console edge by the floor. (You may have to place your fingers further down on the ProClip and press towards the center console for the angled edge to hook under console edge)

3. The ProClip is in place

4. The ProClip is in place.