

Manual, Assembly instruction: Brodit 833379

Console mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Press the angled edge on the left part of the ProClip into the gap between the panel surrounding the gear shift and the console.
2. Pull the long right part of the ProClip downwards and hook under the edge of the console.
3. Press the right part of the ProClip towards the console so the velcro attaches.
4. The ProClip is in place.