

Manual, Assembly instruction: Brodit 833484

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Hook the left part of the ProClip over the edge of the console frame.
2. Press downwards on the right side of the ProClip so the angled edge snaps into the gap between the console frame and the console sidewall.
3. The ProClip is in place.
4. The ProClip is in place.