

Manual, Assembly instruction: Brodit 833548

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap in the console sidewall, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Place the ProClip over the console edge.

3. Press firmly down on the right side of the ProClip so the angled edge snaps into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.