

Manual, Assembly instruction: Brodit 833604

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the left side of the ProClip into the gap between the panel surrounding the gear shift and the edge of the console.
2. Press downwards on the right side of the ProClip so the angled edge hooks under the edge of the console.
3. Press the right side of the ProClip towards the console side wall so the adhesive tape attaches.
4. The ProClip is in place.