

Manual, Assembly instruction: Brodit 833617

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap in the console side wall, to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Press the left part of the ProClip into the gap between the panel surrounding the gear shift and the console.

3. Press downwards on the right side of the ProClip so the angled right edge hooks into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.