

Manual, Assembly instruction: Brodit 833625

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the center console panel frame and the padded console edge, to widen the gap. Place the ProClip over the console edge and press the grooved edge on the left side of the ProClip into the gap in front of the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

2. Place your fingers behind the right side of the ProClip. Pull towards you so the angled edge goes clear of the leather and place the angled edge towards the gap in the sidewall. Press the thin end of the enclosed gap opener into the gap in the sidewall, to widen the gap.

3. Press firmly towards the lower part of the ProClip so the angled edge goes into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.