

Manual, Assembly instruction: Brodit 833699

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the left side of the ProClip into the gap between the console edge and the center console panel frame.

2. Press firmly down on the right side of the ProClip so the angled edge hooks over the console edge by the floor. Press until you see or hear/feel it snaps into place.

3. The ProClip is in place.

4. The ProClip is in place.