

Manual, Assembly instruction: Brodit 833814

Console mount NOT for the S models.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip can be attached on the right as well as the left side of the floor console. The same installation procedure applies for both positions.

1. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the left part of the ProClip over the edge of the console.
2. Press downwards on the right side of the ProClip so the angled edge on the right part of the ProClip hooks under the console by the floor.
3. Press on the ProClip, towards the floor console, so the adhesive tapes attach.
4. The ProClip is in place.