

Manual, Assembly instruction: Brodit 833854

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Place the angled edge on the left side of the ProClip into the gap between the cup holder door and the padded console edge. (The door will still open freely)

2. Press down on the right side of the ProClip so the angled edge hooks under the console edge by the carpet. Press until you see or hear/feel it snaps into place.

3. The ProClip is in place.

4. The ProClip is in place.