

Manual, Assembly instruction: Brodit 833871

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the gear shift and the console, to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Press the curved edge on the left part of the ProClip into the gap next the gap opener. Flip the ProClip rightwards/downwards so the curved left edge hooks under the panel surrounding the gear shift.

3. Press downwards on the right side of the ProClip so the angled edge on the right part hooks under the edge of the console. Pull out the gap opener.

4. The ProClip is in place.