

Manual, Assembly instruction: Brodit 833912

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Press the thin edge on the left side of the ProClip into the gap above the between the center console panel and the console edge.

2. Press firmly down on the right side of the ProClip so the angled edge hooks under the console edge by the carpet.

3. The ProClip is in place.

4. The ProClip is in place.