

Manual, Assembly instruction: Brodit 833938

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the center console sidewall and the console edge, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Place the ProClip over the console edge.

3. Press firmly down on the right side of the ProClip so the angled edge goes into the gap between the gap openers. Press until you see or hear/feel it snaps into place. Pull out the gap openers.

4. The ProClip is in place.