

Manual, Assembly instruction: Brodit 833976

Console mount, Left

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of one of the enclosed Gap Opener (Spaltöffner)s into the gap between the panel surrounding the gear shift and the floor console frame, to widen the gap. Press the gooved edge on the right part of the ProClip into the gap next to the Gap Opener (Spaltöffner). Press until you hear + feel it snaps into place. Pull out the Gap Opener (Spaltöffner).

2. Press both Gap Opener (Spaltöffner)s into the gap in the floor console frame. Press the ProClip leftward so the gooved edge on the left part of the ProClip goes into the gap between the Gap Opener (Spaltöffner)s. Press until you hear + feel it snaps into place. Pull out the Gap Opener (Spaltöffner)s.

3. The ProClip is in place.

4. The ProClip is in place.