

Manual, Assembly instruction: Brodit 834009

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Press the curved edge on the right part of the ProClip into the gap in the floor console sidewall. Flip the ProClip upwards, towards the gear shift.
2. Place your hands on the right side of the ProClip and press it towards the gear shift so the angled edge on the left side goes into the gap between the console edge and the center console panel.
3. Press firmly down on top of the ProClip to make sure the angled edge is all the way into the gap.
4. The ProClip is in place.