

Manual, Assembly instruction: Brodit 834028

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Place the angled edge on the left side of the ProClip over the console edge.

2. Press firmly down on the right side of the ProClip so the angled edge hooks around the console sidewall edge by the floor. Press until you see or hear/feel it snaps into place.

3. The ProClip is in place.

4. The ProClip is in place.