

Manual, Assembly instruction: Brodit 834201

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Place the angled edge on the left side of the ProClip into the gap between the wood grain door and the console edge.
2. Press firmly down on top of the right side of the ProClip so the angled edge hooks around the console sidewall edge by the carpet.
3. Press down on the right side of the ProClip until you see or hear/feel it hook into place.
4. The ProClip is in place. Note: the wood grain door will open and close freely with the ProClip attached.