

Manual, Assembly instruction: Brodit 834279

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap openers into the gap between the panel surrounding the gear shift and the console frame, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Press the left part of the ProClip into the gap between the gap openers. Pull out the gap openers.
3. Press the right side of the ProClip downward so the angled edge hooks under the console edge.
4. The ProClip is in place.