

Manual, Assembly instruction: Brodit 834289

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of the adhesive tape on the ProClip. Hook the angled edge on the upper part of the ProClip over the console edge.

2. Press the right side of the ProClip downward so the angled right edge hooks under the edge of the console.

3. Press the ProClip toward the console so the angled edge hooks properly in place and the adhesive tape attaches.

4. The ProClip is in place.