

Manual, Assembly instruction: Brodit 834333

Console mount ONLY for column gear shift.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the angled edge on the left part of the ProClip over the console edge.

2. Press downward on the right side of the ProClip so the angled edge hooks under the edge of the console. Press until you hear/feel it snaps into place.

3. The ProClip is in place.

4. The ProClip is in place.