

Manual, Assembly instruction: Brodit 834334

Console mount ONLY for floor gear shift.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the gear shift and the console edge, to widen the gap. Peel off the adhesive tape cover on the ProClip.
2. Press the angled edge on the left part of the ProClip into the gap next to the gap opener.
3. Press downward on the right side of the ProClip so the angled edge hooks under the edge of the console. Press until you hear/feel it snaps into place. Pull out the gap opener.
4. The ProClip is in place.