

Manual, Assembly instruction: Brodit 834339

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the left part of the ProClip into the gap between the panel surrounding the gear shift and the console edge.
2. Press downward on the right side of the ProClip so the angled edge hooks around the console edge.
3. Press the lower part of the ProClip toward the console side wall to make sure the angled edge is properly hooked around the console edge.
4. The ProClip is in place.