

Manual, Assembly instruction: Brodit 834348

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the gear shift and the console, to widen the gap. Peel off the cover of the adhesive tape on the ProClip. Hook the angled edge on the lower part of the ProClip under the edge of the console
2. Press the ProClip leftward so the angled left edge hooks into the gap next to the gap opener.
3. Press down on the left side of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.