

Manual, Assembly instruction: Brodit 834350

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the upper part of the ProClip into the gap between the console frame and sidewall.
2. Press the right side of the ProClip downward.
3. Hook the angled lower edge under the edge of the console.
4. The ProClip is in place.