

Manual, Assembly instruction: Brodit 834366

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the left side of the ProClip into the gap between the center panel and the console edge.

2. Press firmly down on top of the right side of the ProClip so the angled edge hooks around the console sidewall edge by the carpet. Press until you see or hear/feel it click into place.

3. The ProClip is in place.

4. The ProClip is in place.