

Manual, Assembly instruction: Brodit 834377

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the seam/gap between the center panel and the console edge, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Press the angled edge on the left side of the ProClip into the gap in front of the gap opener. Pull out the gap opener.
3. Press firmly down on the right side of the ProClip so the angled edge hooks around the console sidewall edge by the carpet.
4. The ProClip is in place.