

Manual, Assembly instruction: Brodit 834416

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Place the angled edge on the left side of the ProClip over the console edge.

2. Press down on the right side of the ProClip so the angled edge hooks around the console edge by the carpet.

3. The ProClip is in place.

4. The ProClip is in place.