

Manual, Assembly instruction: Brodit 834423

Console mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of the adhesive tape on the ProClip. Press the angled edge on the lower part of the ProClip into the gap in the console sidewall.

2. Press the ProClip upward/leftward so the angled lower edge hooks behind the lower section of the console sidewall.

3. Pull the upper part of the ProClip upward and hook the angled left edge over the edge of the console. Press down on the left part of the ProClip so the adhesive tape attaches.

4. The ProClip is in place.