

Manual, Assembly instruction: Brodit 834426

Console mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap openers into the gap between the console panel and the console edge, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the left part of the ProClip into the gap between the gap openers.

2. Press downward on the right side of the ProClip so the angled edge hooks under the edge of the console. Pull out the gap openers.

3. The ProClip is in place, model with manual gear shift.

4. The ProClip is in place, model with automatic gear shift.